


Lab 4(A) Computer Networks

Object: Configuring DHCP server and DHCP client.

Software: Cisco Packet Tracer Student Version.

Procedure:


Step 1: Select 1 Server, 1 switch and 3 End PCs.



Step 2: Connect Device.

• Connect server to switch and switch to all end PCs through a Copper straight-through wire.






Step 3: Configuring DHCP

- Click on Server0 and on the services tab select DHCP, turn on the service give IP 192.168.0.2, Subnet Mask 255.255.255.248, set Maximum Number of Users 6 and then click add.
- After that go to Config tab select FastEthenet0 and select the DHCP radio button.





• After that click each PC, select Config tab click on FastEthernet0 then select DHCP radio.

Step 4: Check Connection Between Devices.

Here the server automatically provide or set the IPs of End Devices. So to check the connect add simple PDU from device to device if successfully delivered means the connections are established



